



## PANEL REPAIR KIT **INSTRUCTIONS**

CONTENTS:

INSTRUCTION SHEET CUTTING TOOL W/2 BLADES PLUG KIT INSERTION TOOL




1.) LOCATE LEAK & MARK THE TUBE TO BE PLUGGED: SEE FIGURE-1.




2.) USING THE SUPPLIED CUTTING TOOL, CUT AWAY A 1-1/2" SECTION FROM THE MARKED TUBE AS SHOWN (BOTH ENDS). SEE FIGURE-2.

## NOTE

- A.) CUT TUBE WITH TOOL MOVING AWAY FROM HEADER
  B.) REMOVE ENTIRE TOP HALF OF TUBE
  C.) ENDS OF SLOT SHOULD BE ROUND & SMOOTH
  D.) BE CAREFUL NOT TO CUT ADJACENT TUBES



3.) WET THE CUT OUT AREA OF THE TUBE AND THE RUBBER PLUG WITH WATER. . USE NO OTHER LUBRICANT. SEE FIGURE 3.



4.) INSERT PLUG ONTO INSERTION TOOL & INTO CUT-OUT. PUSH VERY SLOWLY BUT KEEP PLUG MOVING. USE FINGER PRESSURE TO HELP GUIDE PLUG INTO TUBE.

COMPLETELY INSERT PLUG. SEE FIGURE 4

REMOVE INSERTION TOOL WITH A QUICK TWISTING MOTION. SEE FIGURE 5.

REPEAT WITH SECOND PLUG.

