


PRO RACK

ASSEMBLY DETAIL



PRO RACK INSTALLATION DIRECTIONS:

THE PRO RACK IS SHIPPED WITH THE ABOVE COMPONENTS. THESE WILL BE ASSEMBLED USING SIMPLE HAND TOOLS, A 3/8" SOCKET AND A 1/4" DRILL WITH 1/4" BIT.

1. ATTACH MAIN 2" SUPPORT TEE TO THE 6" ANGLE ATTACHED GUSSET (ALIGN GUSSET PLATES IF NECESSARY).
2. ATTACH 1 1/4" SUPPORT BRACE **YELLOW** TO PUNCHED HOLE IN THE UPPER SUPPORT TEE.
3. AFTER BOLTING **YELLOW** SUPPORT BRACE TO THE MAIN SUPPORT, EXTEND APART AND ATTACH REAR SUPPORT (**RED**).
4. ATTACH MIDDLE SUPPORT **GREEN** AND FRONT SUPPORT **BLUE**.
5. ATTACHED THE ANGLE CLIP TO THE LOWER ENDS OF THE VERTICAL SUPPORTS **BLUE, GREEN AND RED**.
6. BOLT THE CROSS BARS (**BLACK**) TO THE ASSEMBLED SUPPORTS (SEE #1 TOP VIEW).
7. COMPLETE THE ASSEMBLY BY INSTALLING THE CROSS BRACE AT THE REAR OF THE RACK. THIS WILL REQUIRE THE DRILLING OF A 1/4" HOLE AND BOLTING THE 1 1/4" ANGLE TO FROM THE LOWER VERTICAL SUPPORT TO THE UPPER VERTICAL SUPPORT (ONLY ONE PER BANK IS REQUIRED).
8. ATTACHED TO ROOF AS PER LOCAL BUILDING CODE REQUIREMENTS.
9. HELPFUL TIP: YOU MAY TURN THE ATTACHMENT CLIPS AT THE END OF LOWER AND MIDDLE LEGS SIDWAYS, THIS WILL ALLOW APPROXIMATELY 3" ADJUSTMENT FOR ATTACHMENT TO ROOF SLEEPERS (RUNNERS).